

Microinjection of *Bactrocera tryoni* (Queensland fruit fly) embryos

How to prepare Alt-R[®] CRISPR-Cas9 ribonucleoprotein complexes for microinjection

Contributed by Amanda Choo, University of Adelaide, Adelaide, South Australia

The method presented here is provided by customers who have used the Alt-R CRISPR-Cas9 System. This can serve as a starting point for using the Alt-R CRISPR-Cas9 System in similar biological systems, but may not be fully optimized for your gene or application. IDT does not guarantee these methods, and application specialists at IDT can only provide general guidance with limited troubleshooting and support.

Materials

Kits and reagents	Ordering information
Enzyme dilution reagents: Option 1: HEPES and KCl Option 2: 1X Phosphate buffered saline (PBS) Option 3: Opti-MEM [®] media	General laboratory supplier General laboratory supplier Thermo Fisher (cat # 51985091)
Alt-R CRISPR-Cas9 crRNA	IDT predesigned and custom crRNA: www.idtdna.com/CRISPR-Cas9
Alt-R CRISPR-Cas9 tracrRNA or Alt-R CRISPR-Cas9 tracrRNA – ATTO [™] 550	IDT (cat # 1072532, 1072533, 1072534) IDT (cat # 1075927, 1075928)
Alt-R S.p. Cas9 Nuclease 3NLS	IDT (cat # 1074181, 1074182)
Nuclease-Free Duplex Buffer	IDT (cat # 11-01-03-01)
Reagents for 10X Injection buffer: Sodium phosphate KCl	General laboratory supplier General laboratory supplier
Nuclease-Free Water	IDT (cat # 11-05-01-14)
HDR template: Ultramer [®] DNA Oligonucleotides	IDT (www.idtdna.com/Ultramer)

See what more we can do for you at www.idtdna.com.

Methods

A. Prepare buffers and enzyme

1. Prepare the Cas9 enzyme working buffer as described in the following table:

Component	Amount	Final concentration
1 M HEPES, pH 7.5	200 μ L	20 mM
1 M KCl	1.5 mL	150 mM
Nuclease-Free Water	~6.5 mL*	—
Final volume	10 mL	—

* Add 6.5 mL of water, verify pH 7.5, and add more water to reach final volume.

Note: 1X PBS or Opti-MEM media can be used in place of Cas9 enzyme working buffer.

2. Before use, thoroughly mix the stock Alt-R S.p. Cas9 enzyme by inverting the tube several times and briefly centrifuge the tube.
3. Dilute Alt-R S.p. Cas9 enzyme to a working concentration (for example, 1 μ g/ μ L).

Note: The molecular weight of the enzyme is 163,700 g/mol. All Alt-R S.p. Cas9 enzymes are provided at a stock concentration of 61 μ M (10 μ g/ μ L).

Example dilution for 1 μ g/ μ L:

Component	Amount (μ L)
Cas9 dilution buffer (step A1)	9
Alt-R Cas9 enzyme	1
Final volume	10

4. Prepare the 10X injection buffer as described in the following table:

Component	Amount	Final concentration
0.1 M Sodium phosphate buffer, pH 6.8*	0.5 mL	1 mM
1 M KCl	2.5 mL	50 mM
Nuclease-Free Water	47 mL	—
Final volume	50 mL[†]	—

* 51 mL of 0.2 M NaH_2PO_4 + 49 mL of 0.2 M Na_2HPO_4 + 100 mL of Nuclease-Free Water, then verify pH 6.8.

[†] Store 1 mL aliquots of the 10X injection buffer at -20°C .

B. Prepare Alt-R CRISPR-Cas9 guide RNA

1. Prepare stock solutions of Alt-R CRISPR-Cas9 crRNAs and tracrRNA.
 - a. Spin down RNA pellet using a microcentrifuge.
 - b. Resuspend each RNA oligo in Nuclease-Free Duplex Buffer to 100 μM final concentrations as described in the following table:

Normalized amount delivered (nmol)*	Volume of resuspension buffer (μL)
2	20
5	50
10	100
20	200
100	1000

* Prepare positive and negative controls using the same methods as for the experimental complexes—ideally using the same lots of buffers. Alt-R CRISPR-Cas9 HPRT Positive Control crRNAs and Alt-R CRISPR-Cas9 Negative Control crRNAs are available at 2 nmol scale. Custom Alt-R CRISPR-Cas9 crRNAs are available at 2 and 10 nmol scales. Alt-R CRISPR-Cas9 tracrRNA is available at 5, 20, and 100 nmol scales.

To calculate your own dilutions, use the IDT Resuspension Calculator at www.idtdna.com/SciTools.

- c. Store stock solutions at -20°C , when not in use.
2. Mix crRNA and tracrRNA in equimolar concentrations in a sterile microcentrifuge tube to create a final duplex concentration of 40 μM :

Component	Amount (μL)	Final concentration
100 μM Alt-R CRISPR-Cas9 crRNA (step B1)	1	~472 ng/ μL
100 μM Alt-R CRISPR-Cas9 tracrRNA (step B1)	1	~887 ng/ μL
Nuclease-Free Duplex Buffer	0.5	—
Final volume	2.5	40 μM (duplex RNA)

3. Heat at 95°C for 5 min.
4. Remove from heat and allow to cool to room temperature (20 – 25°C).

C. Assemble ribonucleoprotein (RNP) complex

1. Mix the following to assemble RNPs for injection:

a. With no donor template for knockout experiments:

Component	Amount (µL)	Final concentration
crRNA:tracrRNA duplex (40 µM) (step B4)	2.5	10 µM*
Diluted Cas9 enzyme (1 µg/µL) (step A3)	3	300 ng/µL
10X Injection buffer (step A4)	1	1X
Nuclease-Free Water	3.5	—
Final volume	10	—

b. With donor template for homology-directed repair (HDR) experiments:

Component	Amount (µL)	Final concentration
crRNA:tracrRNA duplex (40 µM) (step B4)	2.5	10 µM*
Diluted Cas9 enzyme (1 µg/µL) (step A3)	3	300 ng/µL
ssODN (1 µg/µL) [†]	2	200 ng/µL
10X Injection buffer (step A4)	1	1X
Nuclease-Free Water	1.5	—
Final volume	10	—

* The final concentration of the crRNA is ~118 ng/µL and of the tracrRNA is ~222 ng/µL.

† 4 nmol of Ultramer DNA oligo can be used as the single-stranded deoxyoligonucleotide (ssODN) donor template.

Note: 10 µL of injection mix can be used to inject ~300–400 embryos.

2. Incubate at room temperature for 5 min to assemble the RNP complexes.

Note: The injection mix can now be used for embryo microinjections.

For Research Use Only. Not for use in diagnostic procedures.

© 2018 Integrated DNA Technologies, Inc. All rights reserved. Trademarks contained herein are the property of Integrated DNA Technologies, Inc. or their respective owners. ATTO is a trademark of ATTO-TEC GmbH. For specific trademark and licensing information, see www.idtdna.com/trademarks. CRS-10110-PR 05/2018

See what more we can do for you at www.idtdna.com.